

V-LFP4850

Vision Technology delivers safe lithium iron phosphate Battery solutions for Telecom application.

Overview

The V-LFP4850 back-up lithium iron phosphate battery system is developed for backup of Telecom equipment. Under normal condition, grid AC power supply to rectifier module and the Telecom loads and charge battery pack; When the AC power fail, rectifier module stop power supply, the battery serves for Telecom equipment, to ensure the Telecom equipment runs normally; when the AC power is switched on again, power rectifier module for Telecom equipment recover to while charge the battery pack



Features

- RS485 communication output for monitoring
- Built-in BMS with Charging current limitation
- Built-in automatic protection for over-charge,
 Over-discharge and over-temperature conditions
- State of charge and state of health indication
- Built-in battery control for efficient operation
- Internal cell balancing
- Compatible with standard Telecom rectifiers
- Maintenance free

Specifications	V-LFP4850		
Nominal Voltage	48 V		
Nominal Capacity (@25°C , (50 Ah		
Number of cell	15 cell		
Battery Weight (Approximat	29.8 ±0.5Kg		
Dimensions (W*D*H)	Width*Depth* Height	(442mm*440mm*133mm) ±2	
	Normal energy (@25°C , 0.2C)	2400Wh	
Energy	Volumetric energy density	92Wh/L	
	Gravimetric energy density	82Wh/kg	
	Cell model	36130162LFP05	
	Cell Voltage (Nominal)	3.2 V	
Cell	Cell Capacity (Nominal)	50 Ah	
	Gravimetric energy density of cell	112 Wh/kg	
Internal Impedance @25°C	≤ 40mΩ		
Standard Discharge @25°C	Max. constant current	50A	
	Cut-off voltage	42V	
	Charge Voltage	52.5V ~ 54V	
Standard charge @25°C	Max. constant current	50A	
	Recommended charging current and time	10A(0.2C) for 5.2 hours	
Discharge/Charge efficiency	≥ 95%		
Calendar life @25°C	≥ 12 years		
Cycle life (@ 25°C, 0.2C)		80% DOD 4000 cycles	
Operating temperature	Charging: 0°C ~ 60°C		
Operating temperature		Discharging: -10°C ~60°C	
Storage temperature	Recommended range: 0°C ~ 45°C		
Operating humidity (@40±2	5% ~ 95 <u>%</u>		
Counting function of workin	YES		
Maintain port	YES (Option)		
Anti-theft	Customization screw (Option)		



BMS Parameters.

N	N Type		Function	Setting value	Demerke
0.			Function	V-LFP4850	Remarks
1	– C – Voltage	Chargo	Cell Voltage Protection	3.7Alarm/3.8V Protection	Recover at 3.6V
2		Charge	Total Voltage Protection	56Alarm/57V Protection	Recover at 54V
3		Discharge	Cell Voltage Protection	2.9Alarm/2.8V Protection	Recover at 3.1V
4			Total Voltage Protection	43.2Alarm/42V Protection	Recover at 45V
5	Ctrrent Disc	Charge	Normal	≤50A	
6			Normal	≤50A	
7		Discharge	Over Current Protection 1	Alarm>55A / Protection>60	Delay 20s ,recovery in every 1min
		Discharge	Over Current Protection 2	>90A and $<$ 300A	Delay 3s ,recovery in every 1min
8			Short Circuit Protection	≥300A	Delay 300uS
9	9 10 Temp 11	Cell Temp	Low temp protection	Charging $<$ -10°C Discharging $<$ - 20°C	Delay 1~2S
10			High temp protection	Charging: Alarm >65°C/70°C Protection Discharging: Alarm>70°C/75°C Protection	Delay 1~2S
11		РСВ	High temp protection	Alarm>90°C/>115°C Protection	Recovery at 85°C
12	Cell Balance	Balance	Make all cells be balance during charging process. Current: 150mA	V _{Max} .≥3.40V and V _{Max} V _{Min} ≥40mV, Start balance	All cell voltages $<3.4V$ or V _{Max.} - V _{Min} \leq 40mV, or discharge Stop balance

Battery Status.

- 1. **Stop/Transport Mode**. In working mode, press Start/Stop button, Battery will go to STOP mode with low self-discharge. In STOP mode, charging MOS and discharging MOS are open, battery cannot charge, discharge or communicate.
- 2. Working Mode. In STOP mode, connect the battery to SMPS, press Start/Stop button, battery will go to working mode. In working mode, BMS will monitor battery voltage, current, and temp, and communication is available, charging MOS and discharging MOS are closed, Battery will operate as the settings.
- 3. **Sleep Mode**. After turn on the battery, if the battery voltage below low voltage protection, BMS will go to sleep mode in 1 minute. In sleep mode, charging MOS and discharging MOS are closed, BMS will check the current in every 1 min, if there is charging current connecting, battery will turn to working mode.
- 4. Error Mode. In working mode, if there is: ①. Battery cells, ΔU>1V, or ②. Any cell voltage>3.9V or <2.3V, or ③. Battery temp is <-20°C or +75°C. BMS will go to error mode, ALM will bright and other LED will shut down, and go to STOP mode, charging MOS and discharging MOS are open. Need to make troubleshoot.



Performance Curve.

8500

7000

5500

4000

2500

1000

Number of cycles



Cycle life versus depth of discharge and temperature

at 0.2C

at 0.5 C

Self-discharge at different temperature









Performance may vary depending on, but not limited to cell usage and application. If cell is used outside specifications, performance will diminish. All specifications are subject to change without notice. All information provided herein is believed, but not guaranteed, to be current and accurate.